What's On TV?

There's more than one way to see what's showing on TV.

Info Button

Press Info and you will see the name and a description of the current program at the top of the screen.

OK Button

Press OK to show the 'Now Playing' bar and you will see what program is currently playing.

Guide Button

This is the most comprehensive view of what's on. Go ahead and page through...you're bound to find something to watch.

Browse Button

Press Browse (right arrow) to show the channel you are currently tuned to at the top of the screen. At the bottom of the screen, the 'Info Bar' shows you the channel number, channel name, current date and time, program name, date and time the program airs, a progress bar, and the program that airs next.



Yesterday. Today. Tomorrow. utma.com

Langdon Office

411 7th Ave. P.O. Box 729 Langdon, ND 58249 701.256.5156

Rolla Office

617 Main Ave. West P.O. Box 238 Rolla, ND 58367 701.477.1101

Bottineau Office

538 11th St. W, Suite 2 (located in North Central Electric Building) Bottineau, ND 58318 701.228.1101

This institution is an equal opportunity provider and employer.

0519 BBRG





Controlling the Remote

TV, Set-Top Box

Use one remote to control multiple devices.

Menu

Displays the menu.

Arrow Keys and OK/Sel -

Navigate and select onscreen choices.

Guide ·

Opens the Interactive Program Guide.

Red, Green, Yellow, Blue

Access additional features on your set-top box.

Vol +/-

Raises or lowers the volume.

On Demand

Access video on demand services.

Mute

Turns the sound off or on.

Aspect Ratio*

Temporarily changes the conversion mode from Original Size or Fit to Screen.



Off

Turns on/off a selected device.

Info

Displays the current channel and program information. Press again for more detail.

Exit

Exits the current screen.

Page +/-

Pages up or down in lists and Interactive Program Guide.

Channel +/-

Changes to the next higher or lower channel.

Last

Recalls the last channel you were watching.

FAV

View your favorite channels.

Number keys (0-9)

Directly select a channel or enter options.

Input

In TV control mode, will change the input of the device you are controlling.